

## MODELS 430/F, 430/O and 430/S - Door Lock Installation

### PROCEDURE: (Refer to the illustration below)

1. Using two 1/4 - 20 x 3/4" tamper-proof screws, secure the catch to the bottom cabinet hinge holes on the handle side of the appliance. Tighten the catch to a sliding fit.
2. Attach door lock assembly to housing.
3. Using the two #10-24 x 1/2" socket head cap screws and the hex key, fasten the lock assembly and housing to the bottom of the door through the two holes spaced 1-13/16" apart.
4. Install the cam onto the lock using the #10 screw so that a clockwise rotation will lock the door.
5. Adjust the catch plate for a proper fit. Check the lock for proper operation. Tighten the catch plate screws.
6. Slide the lock cover into position and secure using two #10-24 x 1/2" tamper-proof screws.

